



IMPRESORAS DE INYECCIÓN DE TINTA

IMPRESORAS LÁSER

IMPRESORAS DE INYECCIÓN DE TINTA

DCP

[DCP 130C](#); [DCP 135C](#); [DCP 145C](#); [DCP 150C](#); [DCP 153C](#); [DCP 155C](#); [DCP 163C](#); [DCP 165C](#); [DCP 167C](#); [DCP 185C](#); [DCP 195C](#); [DCP 197C](#); [DCP 330C](#); [DCP 350C](#); [DCP 353C](#); [DCP 357C](#); [DCP 365CN](#); [DCP 373CW](#); [DCP 375CW](#); [DCP 383C](#); [DCP 385C](#); [DCP 387C](#); [DCP 390CN](#); [DCP 395CN](#); [DCP 535CN](#); [DCP 540CN](#); [DCP 560CN](#); [DCP 585CW](#); [DCP 595CN](#); [DCP 750CN](#); [DCP 750CW](#); [DCP 770CW](#); [DCP 6690CW](#); [DCP J125](#); [DCP J132W](#); [DCP J140W](#); [DCP J152W](#); [DCP J172W](#); [DCP J315W](#); [DCP J497DW](#); [DCP J515W](#); [DCP J522DW](#); [DCP J525W](#); [DCP J552DW](#); [DCP J562DW](#); [DCP J572DW](#); [DCP J725DW](#); [DCP J752DW](#); [DCP J772DNW](#); [DCP J772DW](#); [DCP J774DW](#); [DCP J925DW](#); [DCP J1200W](#); [DCP J4110DW](#); [DCP J4120DW](#).

FAX

[FAX 1355](#); [FAX 1360](#); [FAX 1460](#); [FAX 1560](#); [FAX 1860](#); [FAX 1960](#); [FAX 2480C](#); [FAX 2580C](#).

MFC

[MFC 230C](#); [MFC 235C](#); [MFC 240C](#); [MFC 250C](#); [MFC 255CW](#); [MFC 257CW](#); [MFC 260C](#); [MFC 290C](#); [MFC 295CN](#); [MFC 297C](#); [MFC 440CN](#); [MFC 460CN](#); [MFC 465CN](#); [MFC 480CN](#); [MFC 490CN](#); [MFC 490CW](#); [MFC 495CN](#); [MFC 495CW](#); [MFC J625DW](#); [MFC 630CD](#); [MFC 630CDW](#); [MFC 650CD](#); [MFC 650CDW](#); [MFC 660CN](#); [MFC 665CW](#); [MFC 670CD](#); [MFC 670CDW](#); [MFC 675CD](#); [MFC 675CDW](#); [MFC 680CN](#); [MFC 685CW](#); [MFC 695CDN](#); [MFC 695CDWN](#); [MFC 735CD](#); [MFC 735CDW](#); [MFC 790CW](#); [MFC 795CW](#); [MFC 845CW](#); [MFC 850CDN](#); [MFC 850CDWN](#); [MFC 860CDN](#); [MFC 870CDN](#); [MFC 870CDWN](#); [MFC 880CDN](#); [MFC 880CDWN](#); [MFC 885CW](#); [MFC 930CDN](#); [MFC 935CDN](#); [MFC 935CDWN](#); [MFC 990CW](#); [MFC 3360C](#); [MFC 5460CN](#); [MFC 5490CN](#); [MFC 5860CN](#); [MFC 5890CN](#); [MFC 5895CW](#); [MFC 6490CN](#); [MFC 6490CW](#); [MFC 6890CN](#); [MFC 6890CW](#); [MFC J220](#); [MFC J245](#); [MFC J265W](#); [MFC J410](#); [MFC J415W](#); [MFC J430W](#); [MFC J470DW](#); [MFC J480DW](#); [MFC J491DW](#); [MFC J497DW](#); [MFC J650DW](#); [MFC J680DW](#); [MFC J825DW](#); [MFC J870DW](#); [MFC J880DW](#); [MFC J890DW](#); [MFC J895DW](#); [MFC J1140W](#); [MFC J1150W](#); [MFC J1170W](#); [MFC J1180DWT](#); [MFC J4335DW](#); [MFC J4340DW](#); [MFC J4410DW](#); [MFC J4420DW](#); [MFC J4425DW](#); [MFC J4510DW](#); [MFC J4540DW](#); [MFC J4540DWXL](#); [MFC J4610DW](#); [MFC J4620DW](#); [MFC J4625DW](#); [MFC J4710DW](#); [MFC J5320DW](#); [MFC J5330DW](#); [MFC J5330DW XL](#); [MFC J5335DW](#); [MFC J5335DWF](#); [MFC J5340DW](#); [MFC J5345DW](#); [MFC J5620DW](#); [MFC J5625DW](#); [MFC J5720DW](#); [MFC J5730DW](#); [MFC J5740DW](#); [MFC J5830DW](#); [MFC J5910DW](#); [MFC J5930DW](#); [MFC J6510DW](#); [MFC J6520DW](#); [MFC J6530DW](#); [MFC J6535DW](#); [MFC J6535DW XL](#); [MFC J6540DW](#); [MFC J6710CDW](#); [MFC J6710DW](#); [MFC J6720DW](#); [MFC J6730DW](#); [MFC J6910CDW](#); [MFC J6910DW](#); [MFC J6920DW](#); [MFC J6930DW](#); [MFC J6935DW](#); [MFC J6935DWF](#); [MFC J6940DW](#).

COMPATIBLES



ORIGINALES



DCP J132W; DCP J152W; DCP J172W; DCP J4110DW; DCP J522DW; DCP J552DW; DCP J752DW; MFC J245; MFC J4410DW; MFC J4510DW; MFC J4610DW; MFC J470DW; MFC J4710DW; MFC J650DW; MFC J6520DW; MFC J6720DW; MFC J6920DW; MFC J870DW.

COMPATIBLES



ORIGINALES



DCP J4120DW; DCP J562DW; MFC J1140W; MFC J1150W; MFC J1170W; MFC J1180DWT; MFC J4420DW; MFC J4425DW; MFC J4620DW; MFC J4625DW; MFC J480DW; MFC J5320DW; MFC J5620DW; MFC J5625DW; MFC J5720DW; MFC J680DW; MFC J880DW.

COMPATIBLES



ORIGINALES



MFC J5340DW; MFC J5345DW; MFC J5740DW; MFC J6540DW; MFC J6940DW.

COMPATIBLES



ORIGINALES



COMPATIBLES




ORIGINALES



MFC J4335DW; MFC J4340DW; MFC J4540DW; MFC J4540DWXL.

COMPATIBLES



ORIGINALES



DCP 130C; DCP 135C; DCP 150C; DCP 153C; DCP 155C; DCP 330C; DCP 350C; DCP 353C; DCP 357C; DCP 540CN; DCP 560CN; DCP 750CN; DCP 750CW; DCP 770CW; FAX 1355; FAX 1360; FAX 1460; FAX 1560; FAX 1860; FAX 1960; FAX 2480C; FAX 2580C; MFC 230C; MFC 235C; MFC 240C; MFC 260C; MFC 3360C; MFC 440CN; MFC 460CN; MFC 465CN; MFC 480CN; MFC 5460CN; MFC 5860CN; MFC 630CD; MFC 630CDW; MFC 650CD; MFC 650CDW; MFC 660CN; MFC 665CW; MFC 680CN; MFC 685CW; MFC 845CW; MFC 850CDN; MFC 850CDWN; MFC 860CDN; MFC 870CDN; MFC 870CDWN; MFC 880CDN; MFC 880CDWN; MFC 885CW.

COMPATIBLES



ORIGINALES



DCP 145C; DCP 163C; DCP 165C; DCP 167C; DCP 185C; DCP 195C; DCP 197C; DCP 365CN; DCP 373CW; DCP 375CW; DCP 383C; DCP 385C; DCP 387C; DCP 390CN; DCP 395CN; DCP 535CN; DCP 585CW; DCP 595CN; DCP 6690CW; DCP J125; DCP J140W; DCP J315W; DCP J515W; MFC 250C; MFC 255CW; MFC 257CW; MFC 290C; MFC 295CN; MFC 297C; MFC 490CN; MFC 490CW; MFC 495CN; MFC 495CW; MFC 5490CN; MFC 5890CN; MFC 5895CW; MFC 6490CN; MFC 6490CW; MFC 670CD; MFC 670CDW; MFC 675CD; MFC 675CDW; MFC 6890CN; MFC 6890CW; MFC 695CDN; MFC 695CDWN; MFC 735CD; MFC 735CDW; MFC 790CW; MFC 795CW; MFC 930CDN; MFC 935CDN; MFC 935CDWN; MFC 990CW; MFC J220; MFC J265W; MFC J410; MFC J415W.

COMPATIBLES



ORIGINALES



DCP J525W; DCP J725DW; DCP J925DW; MFC J430W; MFC J5910DW; MFC J625DW; MFC J6510DW; MFC J6710CDW; MFC J6710DW; MFC J6910CDW; MFC J6910DW; MFC J825DW.



COMPATIBLES



ORIGINALES



DCP J497DW; DCP J572DW; DCP J772DNW; DCP J772DW; DCP J774DW; MFC J491DW; MFC J497DW; MFC J890DW; MFC J895DW.

COMPATIBLES



ORIGINALES



MFC J5330DW; MFC J5330DW XL; MFC J5335DW; MFC J5335DWF; MFC J5730DW; MFC J5830DW; MFC J5930DW; MFC J6530DW; MFC J6535DW; MFC J6535DW XL; MFC J6730DW; MFC J6930DW; MFC J6935DW; MFC J6935DWF.

IMPRESORAS LÁSER

DCP

[DCP 7055](#); [DCP 7055W](#); [DCP 7057](#); [DCP 7060D](#); [DCP 7065DN](#); [DCP 7070DW](#); [DCP L2500D](#); [DCP L2510D](#); [DCP L2512D](#); [DCP L2520DW](#); [DCP L2530DW](#); [DCP L2537DW](#); [DCP L2540DN](#); [DCP L2550DN](#); [DCP L2560DW](#); [DCP L2620DW](#); [DCP L2627DW](#); [DCP L2627DWE](#); [DCP L2627DWXL](#); [DCP L2660DW](#); [DCP L2665DW](#); [DCP L3515CDW](#); [DCP L3520CDW](#); [DCP L3520CDWE](#); [DCP L3555CDW](#); [DCP L3560CDW](#); [DCP L5500DN](#); [DCP L5510DW](#); [DCP L6600DW](#).

FAX

[Fax 2840](#); [Fax 2845](#); [Fax 2940](#).

HL

[HL 2130](#); [HL 2132](#); [HL 2135](#); [HL 2135W](#); [HL 2240](#); [HL 2240D](#); [HL 2250DN](#); [HL 2270DW](#); [HL L2300D](#); [HL L2310D](#); [HL L2340DW](#); [HL L2350DW](#); [HL L2357DW](#); [HL L2360DN](#); [HL L2365DW](#); [HL L2370DN](#); [HL L2372DN](#); [HL L2375DW](#); [HL L2395DW](#); [HL L2400DW](#); [HL L2400DWE](#); [HL L2445DW](#); [HL L2447DW](#); [HL L2865DW](#); [HL L3215CW](#); [HL L3220CW](#); [HL L3220CWE](#); [HL L3240CDW](#); [HL L5000D](#); [HL L5100DN](#); [HL L5100DNT](#); [HL L5100DNTT](#); [HL L5200DW](#); [HL L5200DWT](#); [HL L5210DN](#); [HL L5210DW](#); [HL L6210DW](#); [HL L6250DN](#); [HL L6300DW](#); [HL L6300DWT](#); [HL L6400DW](#); [HL L6400DWT](#); [HL L6400DWTSP](#); [HL L6400DWTT](#); [HL L6410DN](#); [HL L6450DW](#); [HL L8230CDW](#); [HL L8240CDW](#).

MFC

[MFC 7360](#); [MFC 7360N](#); [MFC 7460](#); [MFC 7460DN](#); [MFC 7860DW](#); [MFC L2700DN](#); [MFC L2700DW](#); [MFC L2710DN](#); [MFC L2710DW](#); [MFC L2712DN](#); [MFC L2712DW](#); [MFC L2713DW](#); [MFC L2715DW](#); [MFC L2720DW](#); [MFC L2730DW](#); [MFC L2732DW](#); [MFC L2735DW](#); [MFC L2740DW](#); [MFC L2750DW](#); [MFC L2800DW](#); [MFC L2827DW](#); [MFC L2827DWXL](#); [MFC L2860DW](#); [MFC L2860DWE](#); [MFC L2960DW](#); [MFC L2980DW](#); [MFC L3740CDW](#); [MFC L3740CDWE](#); [MFC L3760CDW](#); [MFC L5700DN](#); [MFC L5710DN](#); [MFC L5710DW](#); [MFC L5750DW](#); [MFC L6710DW](#); [MFC L6800DW](#); [MFC L6800DWT](#); [MFC L6900DW](#); [MFC L6900DWT](#); [MFC L6900DWTSP](#); [MFC L6910DN](#); [MFC L6950DW](#); [MFC L8340CDW](#); [MFC L8390CDW](#).

COMPATIBLES



ORIGINALES




DCP L3515CDW; DCP L3520CDW; DCP L3520CDWE; DCP L3555CDW; DCP L3560CDW; HL L3215CW; HL L3220CW; HL L3220CWE; HL L3240CDW; HL L8230CDW; HL L8240CDW; MFC L3740CDW; MFC L3740CDWE; MFC L3760CDW; MFC L8340CDW; MFC L8390CDW.

COMPATIBLES



ORIGINALES




DCP 7055; DCP 7055W; DCP 7057; DCP 7060D; DCP 7065DN; DCP 7070DW; Fax 2840; Fax 2845; Fax 2940; HL 2130; HL 2132; HL 2135; HL 2135W; HL 2240; HL 2240D; HL 2250DN; HL 2270DW; MFC 7360; MFC 7360N; MFC 7460; MFC 7460DN; MFC 7860DW.

COMPATIBLES



ORIGINALES




DCP L2500D; DCP L2520DW; DCP L2540DN; DCP L2560DW; HL L2300D; HL L2340DW; HL L2360DN; HL L2365DW; MFC L2700DN; MFC L2700DW; MFC L2720DW; MFC L2740DW.



COMPATIBLES



ORIGINALES




DCP L2510D; DCP L2512D; DCP L2530DW; DCP L2537DW; DCP L2550DN; HL L2310D; HL L2350DW; HL L2357DW; HL L2370DN; HL L2372DN; HL L2375DW; HL L2395DW; MFC L2710DN; MFC L2710DW; MFC L2712DN; MFC L2712DW; MFC L2713DW; MFC L2715DW; MFC L2730DW; MFC L2732DW; MFC L2735DW; MFC L2750DW.



COMPATIBLES



ORIGINALES



DCP L2620DW; DCP L2627DW; DCP L2627DWE; DCP L2627DWXL; DCP L2660DW; DCP L2665DW; HL L2400DW; HL L2400DWE; HL L2445DW; HL L2447DW; HL L2865DW; MFC L2800DW; MFC L2827DW; MFC L2827DWXL; MFC L2860DW; MFC L2860DWE; MFC L2960DW; MFC L2980DW.



COMPATIBLES



ORIGINALES




L5500DN; DCP L6600DW; HL L5000D; HL L5100DN; HL L5100DNT; HL L5100DNNT; HL L5200DW; HL L5200DWT; HL L6250DN; HL L6300DW; HL L6300DWT; HL L6400DW; HL L6400DWT; HL L6400DWTSP; HL L6400DWTT; HL L6450DW; MFC L5700DN; MFC L5750DW; MFC L6800DW; MFC L6800DWT; MFC L6900DW; MFC L6900DWT; MFC L6900DWTSP; MFC L6950DW.



COMPATIBLES



ORIGINALES



DCP L5510DW; HL L5210DN; HL L5210DW; HL L6210DW; HL L6410DN; MFC L5710DN; MFC L5710DW; MFC L6710DW; MFC L6910DN.